



# ORGANOID

NATURAL SURFACES

---

by **AUSTARON**  
SURFACES

## Organoid Surface Care & Maintenance

Organoid natural surfaces are basically maintenance-free. Should it at some point be necessary to remove dust or dirt from the surfaces, please follow the following recommendations:

- Gently vacuum with low pressure
- Premium surfaces: wipe down with a damp cloth
- Light & Medium surfaces: gently wipe down with a dry, lint-free cloth
- Avoid rough brushes, aggressive cleaning agents and chemicals

### **For Organoid light on Natural Flax Fleece non-woven and Ecofleece:**

Special care must be taken when cleaning. These are characterised by an open scatter look and low fibre density. Due to the likewise lower binder quantity, the fibres of these surfaces react particularly sensitively to moisture fluctuations. We therefore strongly advise against wiping the surface of Organoid light products with a damp cloth.

**Note:** Due to the moisture absorption of the Natural Flax Fleece non-woven and Ecofleece during wallpapering, the plant fibres become flexible for a short time, but also dry up again. Careful brushing of the surface should therefore only be carried out when it is completely dry.

### **Organoid flooring:**

The floor panels, which are already provided with a PU sealant on delivery, can be vacuumed and cleaned with all standard household grease-dissolving cleaning agents with a damp cloth. Please make sure not to wipe too wet, especially in the joints. To close the joints and meet higher requirements, we recommend the "2K Duo matt" coating system as an additional, subsequent sealant.